

8'-26000 Double-Wall Compartment Tank Extension 26035 (liters)

Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)
0.5	18	30.5	2073	60.5	5436	90.5	9406	120.5	13627
1.0	30	31.0	2121	61.0	5498	91.0	9475	121.0	13697
1.5	43	31.5	2170	61.5	5561	91.5	9544	121.5	13768
2.0	58	32.0	2219	62.0	5623	92.0	9614	122.0	13839
2.5	74	32.5	2268	62.5	5686	92.5	9683	122.5	13910
3.0	91	33.0	2318	63.0	5749	93.0	9752	123.0	13980
3.5	109	33.5	2368	63.5	5812	93.5	9822	123.5	14051
4.0	129	34.0	2418	64.0	5876	94.0	9891	124.0	14122
4.5	150	34.5	2469	64.5	5939	94.5	9961	124.5	14192
5.0	171	35.0	2520	65.0	6003	95.0	10031	125.0	14263
5.5	194	35.5	2571	65.5	6066	95.5	10100	125.5	14334
6.0	217	36.0	2622	66.0	6130	96.0	10170	126.0	14404
6.5	241	36.5	2674	66.5	6194	96.5	10240	126.5	14475
7.0	266	37.0	2726	67.0	6259	97.0	10310	127.0	14545
7.5	292	37.5	2778	67.5	6323	97.5	10380	127.5	14616
8.0	318	38.0	2831	68.0	6387	98.0	10450	128.0	14686
8.5	346	38.5	2883	68.5	6452	98.5	10520	128.5	14757
9.0	374	39.0	2937	69.0	6517	99.0	10590	129.0	14827
9.5	403	39.5	2990	69.5	6582	99.5	10660	129.5	14898
10.0	432	40.0	3044	70.0	6647	100.0	10730	130.0	14968
10.5	462	40.5	3097	70.5	6712	100.5	10800	130.5	15038
11.0	493	41.0	3152	71.0	6777	101.0	10870	131.0	15109
11.5	524	41.5	3206	71.5	6843	101.5	10940	131.5	15179
12.0	556	42.0	3261	72.0	6908	102.0	11011	132.0	15249
12.5	588	42.5	3315	72.5	6974	102.5	11081	132.5	15319
13.0	621	43.0	3371	73.0	7039	103.0	11151	133.0	15389
13.5	655	43.5	3426	73.5	7105	103.5	11222	133.5	15459
14.0	689	44.0	3482	74.0	7171	104.0	11292	134.0	15529
14.5	724	44.5	3537	74.5	7237	104.5	11363	134.5	15599
15.0	759	45.0	3594	75.0	7304	105.0	11433	135.0	15669
15.5	795	45.5	3650	75.5	7370	105.5	11504	135.5	15739
16.0	831	46.0	3706	76.0	7437	106.0	11574	136.0	15809
16.5	868	46.5	3763	76.5	7503	106.5	11645	136.5	15879
17.0	906	47.0	3820	77.0	7570	107.0	11715	137.0	15949
17.5	943	47.5	3877	77.5	7637	107.5	11786	137.5	16018
18.0	982	48.0	3935	78.0	7703	108.0	11857	138.0	16088
18.5	1020	48.5	3993	78.5	7770	108.5	11927	138.5	16158
19.0	1059	49.0	4050	79.0	7838	109.0	11998	139.0	16227
19.5	1099	49.5	4108	79.5	7905	109.5	12069	139.5	16296
20.0	1139	50.0	4167	80.0	7972	110.0	12140	140.0	16366
20.5	1180	50.5	4225	80.5	8040	110.5	12210	140.5	16435
21.0	1221	51.0	4284	81.0	8107	111.0	12281	141.0	16504
21.5	1262	51.5	4343	81.5	8175	111.5	12352	141.5	16574
22.0	1304	52.0	4402	82.0	8242	112.0	12423	142.0	16643
22.5	1346	52.5	4461	82.5	8310	112.5	12493	142.5	16712
23.0	1389	53.0	4521	83.0	8378	113.0	12564	143.0	16781
23.5	1432	53.5	4581	83.5	8446	113.5	12635	143.5	16850
24.0	1475	54.0	4640	84.0	8514	114.0	12706	144.0	16919
24.5	1519	54.5	4701	84.5	8582	114.5	12777	144.5	16987
25.0	1563	55.0	4761	85.0	8650	115.0	12847	145.0	17056
25.5	1608	55.5	4821	85.5	8719	115.5	12918	145.5	17125
26.0	1653	56.0	4882	86.0	8787	116.0	12989	146.0	17193
26.5	1698	56.5	4943	86.5	8856	116.5	13060	146.5	17262
27.0	1744	57.0	5004	87.0	8924	117.0	13131	147.0	17330
27.5	1790	57.5	5065	87.5	8993	117.5	13202	147.5	17398
28.0	1836	58.0	5126	88.0	9061	118.0	13272	148.0	17467
28.5	1883	58.5	5188	88.5	9130	118.5	13343	148.5	17535
29.0	1930	59.0	5250	89.0	9199	119.0	13414	149.0	17603
29.5	1977	59.5	5311	89.5	9268	119.5	13485	149.5	17671

**8'-26000 Double-Wall Compartment Tank Extension
26035 (liters)**

30.0	2025	60.0	5373	90.0	9337	120.0	13556	150.0	17739
------	------	------	------	------	------	-------	-------	-------	-------

8'-26000 Double-Wall Compartment Tank Extension

26035 (liters)

Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)
150.5	17806	180.5	21645	210.5	24740
151.0	17874	181.0	21704	211.0	24782
151.5	17942	181.5	21763	211.5	24823
152.0	18009	182.0	21822	212.0	24864
152.5	18076	182.5	21880	212.5	24905
153.0	18144	183.0	21938	213.0	24945
153.5	18211	183.5	21996	213.5	24984
154.0	18278	184.0	22054	214.0	25023
154.5	18345	184.5	22112	214.5	25062
155.0	18412	185.0	22169	215.0	25100
155.5	18479	185.5	22227	215.5	25138
156.0	18545	186.0	22284	216.0	25175
156.5	18612	186.5	22340	216.5	25212
157.0	18678	187.0	22397	217.0	25248
157.5	18745	187.5	22453	217.5	25284
158.0	18811	188.0	22509	218.0	25319
158.5	18877	188.5	22565	218.5	25354
159.0	18943	189.0	22620	219.0	25388
159.5	19009	189.5	22676	219.5	25421
160.0	19075	190.0	22731	220.0	25454
160.5	19140	190.5	22786	220.5	25487
161.0	19206	191.0	22840	221.0	25518
161.5	19271	191.5	22895	221.5	25550
162.0	19336	192.0	22949	222.0	25580
162.5	19401	192.5	23003	222.5	25610
163.0	19466	193.0	23056	223.0	25639
163.5	19531	193.5	23109	223.5	25668
164.0	19596	194.0	23163	224.0	25696
164.5	19661	194.5	23215	224.5	25723
165.0	19725	195.0	23268	225.0	25749
165.5	19789	195.5	23320	225.5	25775
166.0	19854	196.0	23372	226.0	25800
166.5	19918	196.5	23424	226.5	25824
167.0	19981	197.0	23475	227.0	25847
167.5	20045	197.5	23526	227.5	25870
168.0	20109	198.0	23577	228.0	25891
168.5	20172	198.5	23627	228.5	25911
169.0	20235	199.0	23678	229.0	25931
169.5	20299	199.5	23728	229.5	25949
170.0	20362	200.0	23777	230.0	25966
170.5	20424	200.5	23826	230.5	25982
171.0	20487	201.0	23875	231.0	25996
171.5	20550	201.5	23924	231.5	26009
172.0	20612	202.0	23972	232.0	26020
172.5	20674	202.5	24020	232.5	26029
173.0	20736	203.0	24068	233.0	26035
173.5	20798	203.5	24115		
174.0	20860	204.0	24162		
174.5	20921	204.5	24209		
175.0	20983	205.0	24255		
175.5	21044	205.5	24301		
176.0	21105	206.0	24347		
176.5	21165	206.5	24392		
177.0	21226	207.0	24437		
177.5	21286	207.5	24481		
178.0	21347	208.0	24525		
178.5	21407	208.5	24569		
179.0	21467	209.0	24613		
179.5	21526	209.5	24656		



CONTAINMENT
SOLUTIONS®

HOW TO PROPERLY GAUGE YOUR TANK:

Underground storage tanks require periodic measurement to determine current inventory level. Using the proper methods when gauging your tank's contents will insure the most accurate reading and insure that you do not damage your tank. The following procedure should be followed whenever you use a gauge stick to determine the amount of product that is in your tank:

- 1) Use a wood dipstick with a rubber or nylon tip. Metallic dipsticks are not recommended. This will insure that frequent tank gaugings or an accidental dropping of the gauge stick into the tank will not damage the tank bottom.
- 2) Slowly lower your gauge stick into the fill port until it touches the tank bottom. Never free drop the gauge stick. This can result in inaccurate measurements due to product splashing. Free dropping can also result in gauge stick damage and tank damage.
- 3) Remove your dipstick slowly and read the product level directly from the gauge stick.

Water Paste Detection:

To detect water in the tank bottom, water detection paste is available from petroleum equipment distributors. See vendor below or suitable equal.

Gasoil Water Finding Paste
Federal Process Corp.
800-846-7325
www.gasoil.com

Caution

Pressurized deliveries are not recommended. If the delivery vehicle uses pumps to fill the tank, install overfill shutoff equipment in the tank and truck to prevent the tank from being overfilled.

Overfilling the tank under pressure will damage the tank even if the tank vent is unrestricted.

Containment Solutions, Inc.
333 North Rivershire Dr., Suite 190
Conroe, TX 77304
Tel: 936-756-7731
Fax: 936-756-7766

Note: Calibration chart is based on the fluid level above a 8mm [5/16"] deflector plate.

**8'-26000 Double-Wall Compartment Tank Extension
26035 (liters)**

180.0	21586	210.0	24698			
-------	-------	-------	-------	--	--	--