

8'-11500 Double-Wall Compartment Tank Extension 11629 (liters)

Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)
0.5	8	30.5	926	60.5	2428	90.5	4201	120.5	6087
1.0	13	31.0	948	61.0	2456	91.0	4232	121.0	6118
1.5	19	31.5	969	61.5	2484	91.5	4263	121.5	6150
2.0	26	32.0	991	62.0	2512	92.0	4294	122.0	6181
2.5	33	32.5	1013	62.5	2540	92.5	4325	122.5	6213
3.0	41	33.0	1035	63.0	2568	93.0	4356	123.0	6245
3.5	49	33.5	1058	63.5	2596	93.5	4387	123.5	6276
4.0	58	34.0	1080	64.0	2624	94.0	4418	124.0	6308
4.5	67	34.5	1103	64.5	2653	94.5	4449	124.5	6339
5.0	76	35.0	1125	65.0	2681	95.0	4480	125.0	6371
5.5	86	35.5	1148	65.5	2710	95.5	4512	125.5	6402
6.0	97	36.0	1171	66.0	2738	96.0	4543	126.0	6434
6.5	108	36.5	1194	66.5	2767	96.5	4574	126.5	6466
7.0	119	37.0	1218	67.0	2796	97.0	4605	127.0	6497
7.5	130	37.5	1241	67.5	2824	97.5	4636	127.5	6529
8.0	142	38.0	1264	68.0	2853	98.0	4668	128.0	6560
8.5	154	38.5	1288	68.5	2882	98.5	4699	128.5	6591
9.0	167	39.0	1312	69.0	2911	99.0	4730	129.0	6623
9.5	180	39.5	1336	69.5	2940	99.5	4761	129.5	6654
10.0	193	40.0	1359	70.0	2969	100.0	4793	130.0	6686
10.5	206	40.5	1384	70.5	2998	100.5	4824	130.5	6717
11.0	220	41.0	1408	71.0	3027	101.0	4855	131.0	6749
11.5	234	41.5	1432	71.5	3056	101.5	4887	131.5	6780
12.0	248	42.0	1456	72.0	3086	102.0	4918	132.0	6811
12.5	263	42.5	1481	72.5	3115	102.5	4950	132.5	6843
13.0	278	43.0	1506	73.0	3144	103.0	4981	133.0	6874
13.5	293	43.5	1530	73.5	3174	103.5	5012	133.5	6905
14.0	308	44.0	1555	74.0	3203	104.0	5044	134.0	6937
14.5	323	44.5	1580	74.5	3233	104.5	5075	134.5	6968
15.0	339	45.0	1605	75.0	3262	105.0	5107	135.0	6999
15.5	355	45.5	1630	75.5	3292	105.5	5138	135.5	7030
16.0	371	46.0	1656	76.0	3322	106.0	5170	136.0	7062
16.5	388	46.5	1681	76.5	3351	106.5	5201	136.5	7093
17.0	404	47.0	1706	77.0	3381	107.0	5233	137.0	7124
17.5	421	47.5	1732	77.5	3411	107.5	5265	137.5	7155
18.0	438	48.0	1758	78.0	3441	108.0	5296	138.0	7186
18.5	456	48.5	1783	78.5	3471	108.5	5328	138.5	7217
19.0	473	49.0	1809	79.0	3501	109.0	5359	139.0	7248
19.5	491	49.5	1835	79.5	3531	109.5	5391	139.5	7279
20.0	509	50.0	1861	80.0	3561	110.0	5422	140.0	7310
20.5	527	50.5	1887	80.5	3591	110.5	5454	140.5	7341
21.0	545	51.0	1914	81.0	3621	111.0	5486	141.0	7372
21.5	564	51.5	1940	81.5	3651	111.5	5517	141.5	7403
22.0	582	52.0	1966	82.0	3682	112.0	5549	142.0	7434
22.5	601	52.5	1993	82.5	3712	112.5	5580	142.5	7465
23.0	620	53.0	2019	83.0	3742	113.0	5612	143.0	7496
23.5	640	53.5	2046	83.5	3773	113.5	5644	143.5	7526
24.0	659	54.0	2073	84.0	3803	114.0	5675	144.0	7557
24.5	678	54.5	2100	84.5	3833	114.5	5707	144.5	7588
25.0	698	55.0	2127	85.0	3864	115.0	5739	145.0	7618
25.5	718	55.5	2154	85.5	3894	115.5	5770	145.5	7649
26.0	738	56.0	2181	86.0	3925	116.0	5802	146.0	7680
26.5	758	56.5	2208	86.5	3956	116.5	5834	146.5	7710
27.0	779	57.0	2235	87.0	3986	117.0	5865	147.0	7741
27.5	799	57.5	2262	87.5	4017	117.5	5897	147.5	7771
28.0	820	58.0	2290	88.0	4048	118.0	5928	148.0	7802
28.5	841	58.5	2317	88.5	4078	118.5	5960	148.5	7832
29.0	862	59.0	2345	89.0	4109	119.0	5992	149.0	7863
29.5	883	59.5	2372	89.5	4140	119.5	6023	149.5	7893
30.0	904	60.0	2400	90.0	4171	120.0	6055	150.0	7923

8'-11500 Double-Wall Compartment Tank Extension

11629 (liters)

Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)
150.5	7954	180.5	9668	210.5	11051
151.0	7984	181.0	9695	211.0	11069
151.5	8014	181.5	9721	211.5	11088
152.0	8044	182.0	9747	212.0	11106
152.5	8074	182.5	9773	212.5	11124
153.0	8104	183.0	9799	213.0	11142
153.5	8134	183.5	9825	213.5	11160
154.0	8164	184.0	9851	214.0	11177
154.5	8194	184.5	9877	214.5	11195
155.0	8224	185.0	9902	215.0	11212
155.5	8254	185.5	9928	215.5	11228
156.0	8284	186.0	9953	216.0	11245
156.5	8313	186.5	9979	216.5	11261
157.0	8343	187.0	10004	217.0	11278
157.5	8373	187.5	10029	217.5	11294
158.0	8402	188.0	10054	218.0	11309
158.5	8432	188.5	10079	218.5	11325
159.0	8461	189.0	10104	219.0	11340
159.5	8491	189.5	10129	219.5	11355
160.0	8520	190.0	10153	220.0	11370
160.5	8549	190.5	10178	220.5	11384
161.0	8579	191.0	10202	221.0	11398
161.5	8608	191.5	10226	221.5	11412
162.0	8637	192.0	10251	222.0	11426
162.5	8666	192.5	10275	222.5	11439
163.0	8695	193.0	10299	223.0	11452
163.5	8724	193.5	10322	223.5	11465
164.0	8753	194.0	10346	224.0	11478
164.5	8782	194.5	10370	224.5	11490
165.0	8811	195.0	10393	225.0	11502
165.5	8839	195.5	10416	225.5	11513
166.0	8868	196.0	10440	226.0	11524
166.5	8897	196.5	10463	226.5	11535
167.0	8925	197.0	10486	227.0	11545
167.5	8954	197.5	10509	227.5	11555
168.0	8982	198.0	10531	228.0	11565
168.5	9010	198.5	10554	228.5	11574
169.0	9039	199.0	10576	229.0	11583
169.5	9067	199.5	10598	229.5	11591
170.0	9095	200.0	10621	230.0	11598
170.5	9123	200.5	10643	230.5	11605
171.0	9151	201.0	10665	231.0	11612
171.5	9179	201.5	10686	231.5	11618
172.0	9207	202.0	10708	232.0	11623
172.5	9235	202.5	10729	232.5	11627
173.0	9262	203.0	10751	233.0	11629
173.5	9290	203.5	10772		
174.0	9317	204.0	10793		
174.5	9345	204.5	10814		
175.0	9372	205.0	10834		
175.5	9400	205.5	10855		
176.0	9427	206.0	10875		
176.5	9454	206.5	10895		
177.0	9481	207.0	10915		
177.5	9508	207.5	10935		
178.0	9535	208.0	10955		
178.5	9562	208.5	10974		
179.0	9589	209.0	10994		
179.5	9615	209.5	11013		
180.0	9642	210.0	11032		



CONTAINMENT
SOLUTIONS®

HOW TO PROPERLY GAUGE YOUR TANK:

Underground storage tanks require periodic measurement to determine current inventory level. Using the proper methods when gauging your tank's contents will insure the most accurate reading and insure that you do not damage your tank. The following procedure should be followed whenever you use a gauge stick to determine the amount of product that is in your tank:

- 1) Use a wood dipstick with a rubber or nylon tip. Metallic dipsticks are not recommended. This will insure that frequent tank gaugings or an accidental dropping of the gauge stick into the tank will not damage the tank bottom.
- 2) Slowly lower your gauge stick into the fill port until it touches the tank bottom. Never free drop the gauge stick. This can result in inaccurate measurements due to product splashing. Free dropping can also result in gauge stick damage and tank damage.
- 3) Remove your dipstick slowly and read the product level directly from the gauge stick.

Water Paste Detection:

To detect water in the tank bottom, water detection paste is available from petroleum equipment distributors. See vendor below or suitable equal.

Gasoil Water Finding Paste
Federal Process Corp.
800-846-7325
www.gasoil.com

Caution

Pressurized deliveries are not recommended. If the delivery vehicle uses pumps to fill the tank, install overfill shutoff equipment in the tank and truck to prevent the tank from being overfilled.

Overfilling the tank under pressure will damage the tank even if the tank vent is unrestricted.

Containment Solutions, Inc.
5150 Jefferson Chemical Road
Conroe, TX 77301
Tel: 936-756-7731
Fax: 936-756-7766

Note: Calibration chart is based on the fluid level above a 8mm [5/16"] deflector plate.