

8'-22000 Double-Wall Compartment Tank Extension 22440 (liters)

Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)
0.5	16	30.5	1787	60.5	4685	90.5	8107	120.5	11745
1.0	26	31.0	1828	61.0	4739	91.0	8167	121.0	11806
1.5	37	31.5	1870	61.5	4793	91.5	8227	121.5	11867
2.0	50	32.0	1913	62.0	4847	92.0	8286	122.0	11928
2.5	64	32.5	1955	62.5	4901	92.5	8346	122.5	11989
3.0	78	33.0	1998	63.0	4955	93.0	8406	123.0	12050
3.5	94	33.5	2041	63.5	5010	93.5	8466	123.5	12111
4.0	111	34.0	2084	64.0	5064	94.0	8526	124.0	12172
4.5	129	34.5	2128	64.5	5119	94.5	8586	124.5	12233
5.0	147	35.0	2172	65.0	5174	95.0	8646	125.0	12294
5.5	167	35.5	2216	65.5	5229	95.5	8706	125.5	12355
6.0	187	36.0	2260	66.0	5284	96.0	8766	126.0	12415
6.5	208	36.5	2305	66.5	5339	96.5	8826	126.5	12476
7.0	229	37.0	2349	67.0	5395	97.0	8886	127.0	12537
7.5	252	37.5	2395	67.5	5450	97.5	8947	127.5	12598
8.0	275	38.0	2440	68.0	5506	98.0	9007	128.0	12659
8.5	298	38.5	2485	68.5	5561	98.5	9067	128.5	12719
9.0	322	39.0	2531	69.0	5617	99.0	9127	129.0	12780
9.5	347	39.5	2577	69.5	5673	99.5	9188	129.5	12841
10.0	372	40.0	2623	70.0	5729	100.0	9248	130.0	12901
10.5	398	40.5	2670	70.5	5785	100.5	9309	130.5	12962
11.0	425	41.0	2716	71.0	5841	101.0	9369	131.0	13023
11.5	452	41.5	2763	71.5	5898	101.5	9430	131.5	13083
12.0	479	42.0	2810	72.0	5954	102.0	9491	132.0	13144
12.5	507	42.5	2858	72.5	6011	102.5	9551	132.5	13204
13.0	536	43.0	2905	73.0	6068	103.0	9612	133.0	13265
13.5	565	43.5	2953	73.5	6124	103.5	9672	133.5	13325
14.0	594	44.0	3001	74.0	6181	104.0	9733	134.0	13385
14.5	624	44.5	3049	74.5	6238	104.5	9794	134.5	13446
15.0	654	45.0	3097	75.0	6295	105.0	9855	135.0	13506
15.5	685	45.5	3146	75.5	6352	105.5	9915	135.5	13566
16.0	717	46.0	3195	76.0	6410	106.0	9976	136.0	13626
16.5	748	46.5	3244	76.5	6467	106.5	10037	136.5	13687
17.0	780	47.0	3293	77.0	6525	107.0	10098	137.0	13747
17.5	813	47.5	3342	77.5	6582	107.5	10159	137.5	13807
18.0	846	48.0	3392	78.0	6640	108.0	10220	138.0	13867
18.5	879	48.5	3441	78.5	6698	108.5	10281	138.5	13927
19.0	913	49.0	3491	79.0	6755	109.0	10342	139.0	13987
19.5	947	49.5	3541	79.5	6813	109.5	10403	139.5	14046
20.0	982	50.0	3591	80.0	6871	110.0	10463	140.0	14106
20.5	1017	50.5	3642	80.5	6930	110.5	10524	140.5	14166
21.0	1052	51.0	3693	81.0	6988	111.0	10585	141.0	14226
21.5	1088	51.5	3743	81.5	7046	111.5	10646	141.5	14285
22.0	1124	52.0	3794	82.0	7104	112.0	10707	142.0	14345
22.5	1160	52.5	3845	82.5	7163	112.5	10768	142.5	14404
23.0	1197	53.0	3897	83.0	7221	113.0	10829	143.0	14464
23.5	1234	53.5	3948	83.5	7280	113.5	10891	143.5	14523
24.0	1271	54.0	4000	84.0	7338	114.0	10952	144.0	14583
24.5	1309	54.5	4052	84.5	7397	114.5	11013	144.5	14642
25.0	1347	55.0	4104	85.0	7456	115.0	11074	145.0	14701
25.5	1386	55.5	4156	85.5	7515	115.5	11135	145.5	14760
26.0	1424	56.0	4208	86.0	7574	116.0	11196	146.0	14819
26.5	1463	56.5	4260	86.5	7633	116.5	11257	146.5	14878
27.0	1503	57.0	4313	87.0	7692	117.0	11318	147.0	14937
27.5	1542	57.5	4366	87.5	7751	117.5	11379	147.5	14996
28.0	1582	58.0	4419	88.0	7810	118.0	11440	148.0	15055
28.5	1623	58.5	4472	88.5	7870	118.5	11501	148.5	15114
29.0	1663	59.0	4525	89.0	7929	119.0	11562	149.0	15172
29.5	1704	59.5	4578	89.5	7988	119.5	11623	149.5	15231
30.0	1745	60.0	4632	90.0	8048	120.0	11684	150.0	15289

8'-22000 Double-Wall Compartment Tank Extension 22440 (liters)

Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)
150.5	15348	180.5	18657	210.5	21324
151.0	15406	181.0	18708	211.0	21360
151.5	15464	181.5	18758	211.5	21396
152.0	15523	182.0	18809	212.0	21431
152.5	15581	182.5	18859	212.5	21466
153.0	15639	183.0	18909	213.0	21501
153.5	15697	183.5	18959	213.5	21535
154.0	15754	184.0	19009	214.0	21568
154.5	15812	184.5	19059	214.5	21602
155.0	15870	185.0	19108	215.0	21635
155.5	15927	185.5	19158	215.5	21667
156.0	15985	186.0	19207	216.0	21699
156.5	16042	186.5	19256	216.5	21731
157.0	16099	187.0	19304	217.0	21762
157.5	16157	187.5	19353	217.5	21793
158.0	16214	188.0	19401	218.0	21823
158.5	16271	188.5	19449	218.5	21853
159.0	16328	189.0	19497	219.0	21882
159.5	16384	189.5	19545	219.5	21911
160.0	16441	190.0	19593	220.0	21940
160.5	16498	190.5	19640	220.5	21968
161.0	16554	191.0	19687	221.0	21995
161.5	16610	191.5	19734	221.5	22022
162.0	16667	192.0	19780	222.0	22048
162.5	16723	192.5	19827	222.5	22074
163.0	16779	193.0	19873	223.0	22099
163.5	16835	193.5	19919	223.5	22124
164.0	16890	194.0	19965	224.0	22148
164.5	16946	194.5	20010	224.5	22171
165.0	17002	195.0	20055	225.0	22194
165.5	17057	195.5	20100	225.5	22216
166.0	17112	196.0	20145	226.0	22238
166.5	17168	196.5	20190	226.5	22259
167.0	17223	197.0	20234	227.0	22279
167.5	17278	197.5	20278	227.5	22298
168.0	17332	198.0	20322	228.0	22316
168.5	17387	198.5	20365	228.5	22334
169.0	17442	199.0	20409	229.0	22350
169.5	17496	199.5	20452	229.5	22366
170.0	17550	200.0	20494	230.0	22381
170.5	17604	200.5	20537	230.5	22395
171.0	17659	201.0	20579	231.0	22407
171.5	17712	201.5	20621	231.5	22418
172.0	17766	202.0	20663	232.0	22428
172.5	17820	202.5	20704	232.5	22435
173.0	17873	203.0	20745	233.0	22440
173.5	17926	203.5	20786		
174.0	17980	204.0	20826		
174.5	18033	204.5	20866		
175.0	18086	205.0	20906		
175.5	18138	205.5	20946		
176.0	18191	206.0	20985		
176.5	18243	206.5	21024		
177.0	18295	207.0	21063		
177.5	18348	207.5	21101		
178.0	18399	208.0	21139		
178.5	18451	208.5	21177		
179.0	18503	209.0	21214		
179.5	18554	209.5	21251		
180.0	18605	210.0	21288		



**CONTAINMENT
SOLUTIONS®**

HOW TO PROPERLY GAUGE YOUR TANK:

Underground storage tanks require periodic measurement to determine current inventory level. Using the proper methods when gauging your tank's contents will insure the most accurate reading and insure that you do not damage your tank. The following procedure should be followed whenever you use a gauge stick to determine the amount of product that is in your tank:

- 1) Use a wood dipstick with a rubber or nylon tip. Metallic dipsticks are not recommended. This will insure that frequent tank gaugings or an accidental dropping of the gauge stick into the tank will not damage the tank bottom.
- 2) Slowly lower your gauge stick into the fill port until it touches the tank bottom. Never free drop the gauge stick. This can result in inaccurate measurements due to product splashing. Free dropping can also result in gauge stick damage and tank damage.
- 3) Remove your dipstick slowly and read the product level directly from the gauge stick.

Water Paste Detection:

To detect water in the tank bottom, water detection paste is available from petroleum equipment distributors. See vendor below or suitable equal.

Gasoila Water Finding Paste
Federal Process Corp.
800-846-7325
www.gasoila.com

Caution

Pressurized deliveries are not recommended. If the delivery vehicle uses pumps to fill the tank, install overfill shutoff equipment in the tank and truck to prevent the tank from being overfilled.

Overfilling the tank under pressure will damage the tank even if the tank vent is unrestricted.

Containment Solutions, Inc.
5150 Jefferson Chemical Road
Conroe, TX 77301
Tel: 936-756-7731
Fax: 936-756-7766

Note: Calibration chart is based on the fluid level above a 8mm [5/16"] deflector plate.